



KRZESŁO CATERINGOWE

Instrukcja obsługi

PL

PRZECZYTAJ UWAŻNIE I ZACHOWAJ NA PRZYSZŁOŚĆ!

Instrukcje Bezpieczeństwa:

Wyłącznie do użytku prywatnego.

Umieść mebel z dala od ognia, grilla lub innego źródła ciepła.

Przed każdym użyciem i po każdym użyciu sprawdź czy krzesło zostało prawidłowo rozłożone. Upewnij się, że mechanizm składanych nóg jest w pełni zablokowany.

Importer:

Mirpol sp. z o.o.

ul. Ciasna 3, 35-232 Rzeszów


biuro@mirpol.rzeszow.pl

www.mirpol.rzeszow.pl

Mirpol

ROZKŁADANIE KRZESŁA

Rozłóż krzesło i umieść na stabilnej powierzchni.
Upewnij się, że nogi znajdują się w prawidłowej pozycji.



UWAGA! upewnij się, że wszystkie śrubki są dokręcone.
Nigdy nie obciążaj krzesła ponad limit wagowy.

Maksymalne obciążenie: 120kg

Składanie i przechowywanie

Aby złożyć krzesło, wykonaj powyższe kroki w odwrotnej kolejności.

Wybierz suche i dobrze przewietrzone miejsce na przechowywanie.

Czyszczenie i pielęgnacja

Należy przechowywać w suchym, zadaszonym miejscu poza użytkowaniem a szczególnie podczas mokrych warunków atmosferycznych.


Aby cieszyć się użytkowaniem mebli przez dłuższy czas, do czyszczenia należy użyć wilgotnej ściereczki i delikatnego detergentu.

Nigdy nie używaj detergentów alkalicznych lub kwaśnych, detergentów na bazie rozpuszczalników, wody chłodem lub pary do czyszczenia krzesła, ponieważ środki te mogą uszkodzić tworzywo.



UNFOLDING THE CHAIR:

Unfold the chair and place it on a stable surface.
Make sure the legs are in the correct position.



CATERING CHAIR

Use Instructions

EN

READ CAREFULLY AND KEEP FOR FUTURE!

Safety instructions:

For private use only.

Place the furniture away from fire, barbecue or other heat source.

Before each use and after each use, check the chair was properly unfolded. Make sure the mechanism the folding legs are fully locked

Importer:
Mirpol sp. z o.o.
ul. Ciasna 3, 35-232 Rzeszów, Poland
biuro@mirpol.rzeszow.pl
www.mirpol.rzeszow.pl

Mirpol

WARNING: ensure all screws are properly secured.
Do not place excessive load on the chair
Maximum load: 120kg

Folding and storage

Reverse the steps above to fold the chair.

Choose a dry and well-ventilated storage place.

Cleaning and care

The product should be stored in a dry, covered place, when out of use, especially in wet weather conditions.

To enjoy the furniture for a long time, use a damp cloth and a mild detergent for cleaning.

Never use alkaline or acid detergents, solvent-based detergents, chlorine water or steam to clean your chair as these chemicals can damage the material.